



## EMO SLAVE SWITCHER UNIT CS6 INSTRUCTIONS FOR USE

**WARNING: TO AVOID ELECTRICAL SHOCK READ THESE INSTRUCTIONS CAREFULLY. ISOLATE ALL MAINS POWER BEFORE WORKING ON THE UNIT.**

These instructions should be read in conjunction with instructions supplied with the CM6 Master Unit.

### Models

---

- EMO SLAVE SWITCHER UNIT CS6 (42-662)

### Control Input

---

Low voltage control inputs marked 1 and 2 should be connected as follows:

Terminal 1 is the control input and should be connected to the chosen output terminal on the master unit (CM6).

If the slave is the first unit then this terminal should be connected to terminal 1 on the master, if the second then connection should be to terminal 2, etc.

Terminal 2 is the common control input and should be connected to terminal 9 or 10 on the master unit.

For further information or servicing please contact your local E.M.O. Dealer.