



BATTERY PHANTOM PSU E720

INSTRUCTIONS FOR USE

Models

- EMO BATTERY PHANTOM PSU E720 (20-720)

Description

Single channel, battery powered, 48 volt microphone phantom power supply.

Low battery indicator.

Battery life, using an alkaline battery – approx. 80 hours.

Dimensions: 110 x 60 x 32mm.

Battery

This unit is powered by a 9V battery; PP3, MN1604, 6LF22, 4022 or equivalent.

The battery is fitted by removing the four lid screws.

Take care not to trap the battery leads when replacing the lid.

The use of an alkaline battery is recommended to ensure long life.

It should be replaced at least annually.

Operation

The unit is turned on by operating the rocker switch on the box lid.

The 'Low Battery' indicator will illuminate for a short time at switch-on. If this does not happen then either the battery is dead or there is no battery fitted.

If the 'Low Battery' light comes on during operation (or does not extinguish after switch-on) then the battery should be replaced as soon as possible.

The unit will continue to supply 48V down to very low battery voltages.

Only use suitable microphones with this 48V phantom power supply.

Do not connect microphones requiring a T-Power supply to this unit.

For further information or servicing please contact your local E.M.O. Dealer.